



HIP HOP

Kullanım Kılavuzu
Operating Instructions


www.tcc.com.tr

TCC[®]
The Chair Company

GRAMMER
office[®]


1. ADIM

Kafalık metalleri arkalıktaki deliklere sokarak kafalığı takın. Kafalığın yüksekliğini ayarlayın.
(Kafalıklı versiyonu için)




2. ADIM

Kolçak yüksekliğini, dirsek eklemlerinin açısı 90 derece olacak şekilde ayarlayın. Gerekirse, en rahat konumu elde etmek için kolçak pedlerini öne doğru kaydırın ve kolçakları eksenleri üzerinde döndürün.




Kolçak yükseklik ayarı:

- Düşmesine basın;
- Kolçağı yukarı/aşağı hareket ettirin.



Kolçak ayarı ileri geri:

Kolçak pedini ileri/geri hareket ettirin.




Kolçak aç ayarı:

Kolçağı sola/sağa döndürün.

3. ADIM

Koltuk yüksekliğini, ayaklarınız yere güvenle basacak ve bacaklarınız 90 derecelik bir açıyla bükülecek şekilde ayarlayın.



4. ADIM

Kolu çekerek mekanizmanın kilidini açın.


Koltuğu ve arkalı 7 konumdan birinde sabitlemek için:

- kolu çekerek mekanizmanın kilidini açın;
- ters hareketle mekanizmayı sapırtın ve blok edin.


DİKKAT! Mekanizmayı sabitlemek için kolun oluklardan birine oturması gerekir!

Serbest salınım için:

- kolu çekerek mekanizmanın kilidini açın.



Çekin




Kilitleme: İtin

AJUSTMENTS

STEP 1


Install the headrest, putting the stocks into the relevant holes in the backrest. Adjust the headrest height (for HR modification).



STEP 2


Adjust the armrest height so that the angle of the elbow joints would be 90 degrees.

If necessary, slide the armrest pads forward and rotate the armrests over their axis to achieve the most comfortable position.




Armrest height adjustment:

- 1 press the button;
- 2 put up/down the armrest.



Armrest adjustment back and forth:

- 1 slide the armrest pad forwards/backwards.




Armrest angle adjustment:

- 1 rotate the armrest left/right

STEP 3

Adjust the seat height so that your feet would be flat on the floor with confidence, and legs would be bent at an angle of 90 degrees.



STEP 4

Unlock the mechanism by pulling off the lever.


To lock the seat and backrest in one of 7 positions:

- unlock the mechanism by pulling off the lever;
- tilt backrest and lock the mechanism by return movement.


ATTENTION! For fixing, the lever should get into one of the grooves!

For free wiggling:

- unlock the mechanism by pulling off the lever.



Pull off



Locking:
Push of
the lever

